


Control Panel: Workcell — System Block Diagram

Control Panel V2.0 · Rev 0.0



—PS1/2/3 isolated through Workcell Control Panel, GND jumpers live on Scaffold Control Panel (JP1-3)