


Control Panel: Scaffold — Block Diagram

Scaffold V2.3 · Rev 0.0



-PS1/2/3 isolated through Workcell Control Panel, GND jumpers live on Scaffold Control Panel (JP1-3)